

BETRIEBSANLEITUNG HITEC SCOOTER

HTCDR 450



Das Zusammenklappen des Scooters / Le pliage du scooter / La piegatura dello scooter



Datasheet

Parameter	Description
Material	Steel or Alluminium
Battery voltage	48V battery
Max Range	25-30 kg
Max Speed	20km/h / 40km/h
Net weight	21.8kg
Max loading	130kg
Climbing Angle	12%
Screen	LED
Tire size	Front 12"/ Rear 12"

Brake Mode	Rear disc-brake Front disc-brake
Unit unfold size	1280*475*940 mm
Unit folded size	1280*280*560mm
Charger	48V2A
Charging time	3 – 4 h
Motor Power	450W
Battery	48V 8Ah Li battery

Das Öffnen des Trittbretts / Ouverture du pied de lit / Apertura della pedana





Verwenden sie dazu den Zündschlüssel


Utilisez la clé de contact

Utilizzare la chiave di accensione

Der Lithium Ionen Akkumulator / L'accumulateur lithium-ion / L'accumulatore agli ioni di litio



Das Herausnehmen des Akkus und externes Laden / Retrait de la batterie et charge externe / Rimozione della batteria e charge externe



Batterieanzeige / kmh/km /Indicateur de batterie / kmh/km /Indicatore batteria /kmh/ km



Ladebuchse unter dem Trittbrett / Prise de charge sous le marchepied / Presa di ricarica sotto il predellino



Generell Information

Loss will be caused during cycling and parking, that will affect the performance of the product. before you ride the bike, you must check the following things:

Check whether the parts of the bike are installed stable and not damaged.

Check if brakes are in perfect condition.

Check if folding mechanism is locked.

Check if there is enough electricity.

Check if the tire is in good condition.

Check if bike handle has any sign of loose, please tighten it if has.

You need to familiar with the environment around you. Make sure you don't disturb by cars, pedestrians, pets, bicycles, and other obstacles.

You need a skilled assistant next to you. The assistant needs to be able to operate the electric bike and understand all the cautions and riding methods in this manual.

Please do not try on the smooth, slippery ground.

Please be sure to wear safety helmets and protective gear to avoid possible damage.

The moisture will cause the brakes to slow down, after cleaning up the electric bike, please dry the brakes in a safe place.

Avoid using this product in bad weather (e.g. snow, rain, or ice).

Use this product in any environment, please check if the brake is normal

Safety precautions

This scooter is a personal mobility tool with a certain speed. Its technology and production are strictly tested. But if you do not ride it according to the warnings of use specified in this manual, may bring you riding risk. No matter when and where, for the reason of the fall, out of control, collision, including not abide by the riding requirements of this manual, that may have the possibility to lead to injury or even death. In order to reduce risk and avoid damage, you must read the manual carefully,

Wear a helmet and protective gear while riding

Do not ride at the slope which is more than 7.2 °, and do not speed up or slow down suddenly on the slope.

Pay attention to obstacles and slippery roads; Don't ride on the grass or crushed stone road.

Do not ride in the water exceed 30mm in depth.

It is forbidden to ride up and down the stairs.

It is forbidden to soak the bike in water.

The bike is a one-man bike that prohibits many people cycling together.

Please make sure the electricity is full and the tire is normal before riding.

Do not try to speed fast before you are familiar with riding. Please speed up slowly.

The special nature of the lithium batteries requires users to charge the bike at least once a month. if the battery damage for not maintenance regularly, that is beyond the scope of the company warranty. The Bike is used only for daily travel. Do not use it as an extreme sport and similar dangerous cycling.

Warranty

We provide 2-year warranty (the bike needs to be ridden in normal way)

Below situation is not in the scope of warranty:

- (1) The shell of the battery is opened.
- (2) The connect jack was broken by human reason.
- (3) The appearance of the bike is broken.
- (4) The failure or damage caused by an irresistible force or a natural disaster (such as a lightning strike).
- (5) **Wearing parts and improper behavior are excluded from the guarantee**

We reserve the right to explain the terms of the event.

Innomatec GmbH

Im Stetterfeld 1 5608 Stetten Switzerland

Phone +41 56 470 11 45

Fax +41 56 470 11 46

www.innomatec.ch